



CURTAIN FOR MINI INWALL PLANT ROOM

FITTING INSTRUCTIONS

The optional curtain is to contain the splash of water when a relief valve discharges.

It is simple to fit and remove to allow unhindered maintenance to be carried out.

To fit the curtain ensure the width of the Velcroed section is of the right length.

Before removing the backing on the velcro to be fitted to the top inside of the housing, sandpaper the fibreglass housing to ensure that the tape will adhere.

The curtain is fitted into the housing in such a manner that the edges are folded inwards, this will retain and direct the water to the drain and allow the valves to be accessed by reaching behind the curtain if needed to close or open when a discharge is occurring.

Ref: \\Yb01\\Files\\SPS\\Brochure & Catalogues\\Electronic Catalogues\\MIWPR\\CURTAIN FOR INWALL VALVE HOUSING.doc

♦ GUTTA SUMP SYSTEM ♦ INWALL TUNDISH ♦ VANDAL-PROOF WALL PANELS ♦ HANGING BRACKET ♦
♦ VANDAL RESISTANT MIRROR ♦